

User's Guide



Shop online at

omega.com[®]

Ω OMEGA[®]

omega.com

e-mail: info@omega.com

For latest product manuals:

omegamanual.info

ISO 9001

CERTIFIED
CORPORATE QUALITY

STAMFORD, CT


ISO 9002

CERTIFIED
CORPORATE QUALITY

MANCHESTER, UK

LVU-700

Ultrasonic Point Level Switches



Installation

The LVU 700 SERIES can be side, top or bottom mounted. **Important: Make sure that all wiring, conduit and electrical fittings conform to local electrical codes for the location selected.**

Visual Inspection: Unpack the control unit and sensor assemblies. Visually inspect them for any damage. Advise Factory immediately if any damage is detected.

Preliminary Operation Check:

Before installing the unit, a simple operational check should be performed as follows:

1. Fill a container with liquid.
2. See wiring diagram for making the proper wiring connections. **Warning! In a hazardous environment never open housing cover or connect power leads without first disconnecting electrical power at the source.**
3. Apply power from the source.
4. Place the sensor in the liquid. Observe output change.
5. Remove sensor from the liquid. Observe output to go back to its initial condition.
6. System is functioning properly.
7. Disconnect power to the control unit.
8. Proceed to the final installation.

(if the system does not function, notify the factory immediately)

Final Installation:


1. Drill a suitable hole in the vessel or pipe wall and tap for 3/4" NPT/ 1/2" NPT/ 1/4" NPT. In thin-walled vessel or material not suitable for threading, weld or braze a bushing to accept the sensor.
2. Screw the sensor into the threaded section and **make sure there is a good seal.** Use a pipe compound or or sealing tape to avoid excessive tightening. **Do not overtighten.**
3. Run the power and control wiring cables to the electronics control unit.

System Malfunction

Should the system malfunction, notify OMEGA Immediately.


DIMENSIONS:

LVU-A701,A703,A707




MATERIAL: 316LSS

LVU-A711,A712,A713




LVU-A714,A715,A716



MATERIAL: 316LSS


SOURCE OUTPUT
GROUND



WIRING DIAGRAMS


**JUMPER WHITE WIRE
TO RED WIRE(+)**

SINK OUTPUT



**JUMPER BROWN WIRE
TO BLACK WIRE(-)**

RELAY OUTPUT





WARRANTY/DISCLAIMER

OMEGA ENGINEERING, INC. warrants this unit to be free of defects in materials and workmanship for a period of **13 months** from date of purchase. OMEGA's WARRANTY adds an additional one (1) month grace period to the normal **one (1) year product warranty** to cover handling and shipping time. This ensures that OMEGA's customers receive maximum coverage on each product.

If the unit malfunctions, it must be returned to the factory for evaluation. OMEGA's Customer Service Department will issue an Authorized Return (AR) number immediately upon phone or written request. Upon examination by OMEGA, if the unit is found to be defective, it will be repaired or replaced at no charge. OMEGA's WARRANTY does not apply to defects resulting from any action of the purchaser, including but not limited to mishandling, improper interfacing, operation outside of design limits, improper repair, or unauthorized modification. This WARRANTY is VOID if the unit shows evidence of having been tampered with or shows evidence of having been damaged as a result of excessive corrosion; or current, heat, moisture or vibration; improper specification; misapplication; misuse or other operating conditions outside of OMEGA's control. Components in which wear is not warranted, include but are not limited to contact points, fuses, and triacs.

OMEGA is pleased to offer suggestions on the use of its various products. However, OMEGA neither assumes responsibility for any omissions or errors nor assumes liability for any damages that result from the use of its products in accordance with information provided by OMEGA, either verbal or written. OMEGA warrants only that the parts manufactured by the company will be as specified and free of defects. OMEGA MAKES NO OTHER WARRANTIES OR REPRESENTATIONS OF ANY KIND WHATSOEVER, EXPRESSED OR IMPLIED, EXCEPT THAT OF TITLE, AND ALL IMPLIED WARRANTIES INCLUDING ANY WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE HEREBY DISCLAIMED. LIMITATION OF LIABILITY: The remedies of purchaser set forth herein are exclusive, and the total liability of OMEGA with respect to this order, whether based on contract, warranty, negligence, indemnification, strict liability or otherwise, shall not exceed the purchase price of the component upon which liability is based. In no event shall OMEGA be liable for consequential, incidental or special damages.

CONDITIONS: Equipment sold by OMEGA is not intended to be used, nor shall it be used: (1) as a "Basic Component" under 10 CFR 21 (NRC), used in or with any nuclear installation or activity; or (2) in medical applications or used on humans. Should any Product(s) be used in or with any nuclear installation or activity, medical application, used on humans, or misused in any way, OMEGA assumes no responsibility as set forth in our basic WARRANTY/DISCLAIMER language, and, additionally, purchaser will indemnify OMEGA and hold OMEGA harmless from any liability or damage whatsoever arising out of the use of the Product(s) in such a manner.

RETURN REQUESTS/INQUIRIES

Direct all warranty and repair requests/inquiries to the OMEGA Customer Service Department. BEFORE RETURNING ANY PRODUCT(S) TO OMEGA, PURCHASER MUST OBTAIN AN AUTHORIZED RETURN (AR) NUMBER FROM OMEGA'S CUSTOMER SERVICE DEPARTMENT (IN ORDER TO AVOID PROCESSING DELAYS). The assigned AR number should then be marked on the outside of the return package and on any correspondence.

The purchaser is responsible for shipping charges, freight, insurance and proper packaging to prevent breakage in transit.

FOR **WARRANTY** RETURNS, please have the following information available BEFORE contacting OMEGA:

1. Purchase Order number under which the product was PURCHASED,
2. Model and serial number of the product under warranty, and
3. Repair instructions and/or specific problems relative to the product.

FOR **NON-WARRANTY** REPAIRS, consult OMEGA for current repair charges. Have the following information available BEFORE contacting OMEGA:

1. Purchase Order number to cover the COST of the repair,
2. Model and serial number of the product, and
3. Repair instructions and/or specific problems relative to the product.

OMEGA's policy is to make running changes, not model changes, whenever an improvement is possible. This affords our customers the latest in technology and engineering.

OMEGA is a registered trademark of OMEGA ENGINEERING, INC.

© Copyright 2005 OMEGA ENGINEERING, INC. All rights reserved. This document may not be copied, photocopied, reproduced, translated, or reduced to any electronic medium or machine-readable form, in whole or in part, without the prior written consent of OMEGA ENGINEERING, INC.